

VIPP921 SHELF, SMALL



Standard brick/concrete rawplugs enclosed

Please make sure to choose rawplugs according to the material on which you want to place the product. Substitute enclosed rawplugs with another type if needed.



Drill size: \varnothing 8mm

Mounting instructions

①

Drill holes and place rawplugs.
(Find drilling template on packaging)

②

Mount, align and level wall brackets.
(The M6 bolt has to be in its hole)

③

Place the shelf and tighten the two
finger screws.

④

Place rubber mats.

