

- CARE GUIDE -

J-SERIES

HAY

Designed to recreate the classic FDB furniture collection, the J-Series offers a functional design born out of industrial development. FDB created a strong furniture concept in 1933, and under Børge Mogensen's leadership as design director from 1942, the FDB furniture linked industrial production closely with architectural furniture design.

The primary focus was not on detailing, but on making well-designed furniture accessible to the general population. The industrial approach eliminated the need for special components and all chairs featured identical legs. FDB revolutionised the industry as a precursor of many of the design icons that Denmark is acknowledged for today around the world.

- CAUTION -

With a little care you can prolong the life of your furniture. Follow the instructions for the materials of your specific product to make sure that it stays in the best shape for as long as possible.

The information below is only intended as a general guideline. For more information on how to remove specific stains, please enquire where you bought the furniture.

/ Always remove stains quickly before they can do any permanent damage to the furniture.

/ Avoid placing the furniture in direct sunlight or near a strong heat source to reduce changes. As wood is a natural material, it will change in colour and will patinate over time.

/ When you move your furniture, make sure you lift it rather than pulling or pushing it to avoid damaging the floor, legs and mountings.

/ Avoid improper use such as sitting on the back or armrests, tilting the seats on their back legs, putting your feet on the furniture or standing on it.

/ Be careful not to scratch or damage the surface with sharp objects.

/ Check the status of the gliders frequently and if worn down, contact your local retailer to buy replacements. The durability of the gliders will depend on the surface the chair is placed on.

/ Avoid partially covering the surface, for example with tablecloths, cushions or skins, as colour variances may appear.

WATER-BASED LACQUERED WOOD

Wipe with a clean cloth wrung in water or in a solution of water and a neutral detergent. Remove soap residue immediately using a clean, dry cloth. If the surface is scratched or appears matt, use a care product specifically suited to lacquered or stained wood. Avoid using detergents containing silicone, as they seal the stain in and make subsequent repairs more difficult. Never use soft soap or solvents such as spirit, turpentine or acetone. Do not use cleaning products containing alcohol, as they may damage the surface. Avoid using scouring cream or scouring pads, as they may scratch the surface.

SOAPED WOOD

Wipe with a clean cloth wrung in water or in a solution of water and a neutral detergent or soap flakes. Remove soap residue immediately using a clean, dry cloth. To remove stains, clean and scrub using a thick solution of soap flakes that should not stay on the wood for more than two minutes. Then remove the remaining soap residue using a damp cloth. If the grain of the wood rises after cleaning, gently sand down the wood using fine-grit sandpaper (No. 220), always sanding in the direction of the grain. If the surface is scratched or appears matt, use a care product specifically suited to soaped wood. Never use soft soap or solvents such as spirit, turpentine or acetone. Do not use cleaning products containing alcohol, as they may damage the surface.

OILED WOOD

Wipe with a clean, dry cloth. If the surface is dirty, wipe with a clean cloth wrung in water or in a solution of water and a neutral detergent or soap flakes. Remove any soap residue immediately using a clean, dry cloth. Never use soft soap or solvents such as spirit, turpentine or acetone. Do not use cleaning products containing alcohol, as they may damage the surface. Avoid using scouring cream or scouring pads, as they may scratch the surface. If the surface is scratched or appears matt, make sure to use an oil hardening care product specifically designed to maintain oiled wooden surfaces. Clean the furniture thoroughly (12 hours) before applying the oil to all surfaces. To ensure optimal absorbency, gently sand down the wood using fine-grit sandpaper (No. 180 or 240), always sanding in the direction of the grain. Apply the oil generously using a clean cloth or a sponge, always sanding in the direction of the grain.

Do not pour the oil directly on the surface. When the surface is glistening, leave the oil on for around two hours until fully absorbed. Remove any excess oil with a clean lint-free cloth. Leave the furniture to dry overnight (min. 12 hours) and avoid placing anything on the surface before it is completely dry. If the grain of the wood rises after oiling, gently sand down the wood using fine-grit sandpaper (No. 180 or 240), always sanding in the direction of the grain. To optimally maintain the naturally beautiful appearance of the wood, we recommend you regularly treat the furniture's surface with oil whenever it appears dull, scratched or as needed.

Havnen 1 8700 Horsens Denmark
+45 4282 0282 / hay@hay.com

HAY