



CARE INSTRUCTIONS

Wipe the parts with a damp cloth soaked in warm water and a bit of mild detergent. Use only soft cloth for wiping and polishing, never sponges or steel wool. Do not use abrasive household cleaners. Do not use acidic or alkaline cleaning materials, glass cleaner or household ammonia.

TROUBLESHOOTING

If lamp does not light, turn off the power. Check the bulb for a broken filament. Replace bulb if necessary, then turn it on. If the lamp still does not light, please contact customer service at the local dealer. If the external flexible cable or cord of this lamp is damaged, it must be replaced by a qualified electrician in order to avoid a hazard.

TECHNICAL INFORMATION

Light sources: E27, max. 57W halogen bulb. Turn power off when changing light bulb. Isolation class II. The lamp is not approved for outdoor use or use in damp/wet rooms (IP20).



For enquiries contact GUBI A/S - CVR: 17940384
Klubiensvej 7-9, 2150 Nordhavn, Copenhagen, Denmark
T +45 69 15 60 60 – order@gubi.dk
GUBI.COM


58-20-008-01 Assembly Instructions Turbo Pendant Ø62 cm & Ø36 cm EU.

GUBI

ASSEMBLY INSTRUCTIONS

for

Turbo Pendant




GUBI

ASSEMBLY INSTRUCTIONS


CONTENTS.

TURBO PENDANT




1.

Attach the ceiling bracket to the ceiling where the mains voltage exits.




2.

Adjust lamp to desired height and cut and strip the wire accordingly.




3.

Pull the kevlar wire through the bracket hole (A), connect to wire lock and tighten strain relief (B).




4.

Open connection box by pushing the pins while pulling the lid up.




5.

Connect mains wire and lamp wire in the screw terminal.



6.

Close connection box and place inside canopy.



7.

Pull up and attach canopy.

